







USER MANUAL 520 & 700 // UNDERMOUNT HOOD ARU52S | ARU70S

IMPORTANT // Please ensure that you read through this user manual prior to installation and use. This manual contains important information to ensure optimal performance and keep you safe. Please retain your proof of purchase, as this will be required in the event that you require warranty service. Remember to retain this manual for future reference.



















HELLO

CONGRATULATIONS ON THE SELECTION OF THIS ARISTON APPLIANCE. ARISTON APPLIANCES HAVE BEEN SPECIFICALLY DESIGNED FOR **AUSTRALIAN AND NEW ZEALAND KITCHENS.**

Please read through this user manual carefully as it contains information that will ensure that your appliance is installed correctly, important operating & care instructions and also some advice of what you need to do if this appliance is not performing as intended.









CONTENTS

HELLO	2
CONTENTS	3
WARNING & SAFETY INFORMATION	4
INSTALLATION & DUCTING	5
OPERATING INSTRUCTIONS	7
MAINTAINING YOUR RANGEHOOD	8
PRODUCT SPECIFICATION	g
PROOF OF PURCHASE	10
NOTES	11
CONTACT DETAILS	12













WARNING & SAFETY INFORMATION

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been supervision given or instruction concerning use of the appliance by a person responsible for their safety.
- Young children should be supervised to ensure that they do not play with the appliance.
- ▲ There shall be adequate ventilation of the room when the rangehood is used at the same time as appliances burning gas or other fuels.
- You must read the details concerning the method and frequency of cleaning.
- ▲ There is a fire risk if cleaning is not carried out in accordance with the instructions.
- Do not flambé under the rangehood.
- Exhaust air must not be discharged into an existing flue which is used for exhausting fumes from appliances burning gas or other fuels.

- The minimum distance between the hob surface and the lowest part of the rangehood is 600mm. This distance shall be at least 650mm, if the rangehood is installed over a gas hob. If the instructions for the gas hob specify a greater distance, this has to be taken into account.
- Attention should be given to ensure that any applicable regulations concerning the discharge of exhaust air is fulfilled.
- If the supply cord of this equipment is damaged, it must only be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid a hazard.
- This appliance has been designed for indoor domestic use only.
- Do not remove or inspect the filters whilst the hood is in operation.





















INSTALLATION & DUCTING





IMPORTANT // Before handling the rangehood during installation, it is recommended that you remove the filter to prevent damage.

Fig 1.2 illustrates the minimum height from the hob surface to the underside of the rangehood. Electric hob – 600mm, Gas hob - 650mm.



NOTICE // If the instructions for the gas hob specify a greater distance, this has to be observed. Any installation above 750mm will compromise performance.






















INSTALLATION & DUCTING



DUCTED OPTION

NOTICE // All ducting material must be compliant with the local laws in force.

INSTALLATION

- 1. Remove the filter and light globes. (If installed)
- 2. Remove the stainless steel fascia (2 screws) take care not to damage the fascia.
- 3. Determine the most efficient path for the ductwork, minimise bends and keep the length of the ductwork to a minimum.
- 4. It is important to run and finish (install roof / wall caps) prior to installation of the hood.
- 5. Cut out the cabinetry as per the installation diagram. Ensure that access has been allowed for the power cable before and after installation.
- 6. Hold the hood up to the underside of the cabinet (2 people required); Screw the hood to the cabinetry. (See Fig 1.3)
- 7. Attach the ducting adaptor to the ducting.
- 8. Re-install the stainless steel fascia.
- 9. Re-install filter.
- 10. Plug in the power to the unit, turn on and test.

WARNING // Do not penetrate any screws into the rangehood as this may result in electrical hazards. Failure to install the screws or fixing device in accordance with these instructions may result in electrical hazards.
























FAN SPEED

The fan is turned on and off by depressing the power button on the control panel. Once the unit has been switch on the required speed can be then be selected; Low, Medium or High.

LIGHT

The light can be operated at all times – even when the fan is not in operation. The light is turned on and off by depressing the light button on the control panel.

CONTROLS

- **b** Power on/off
- → Low speed
- Medium speed
- * High Speed
- Light







pg 7













GENERAL MAINTENANCE

Ensure that the power to the unit is switched off prior to cleaning the unit. Surface should only be cleaned with warm soapy water and a soft non-abrasive cloth. In coastal environments and humid areas more frequent cleaning is required to maintain the finish.

FILTERS

These filters should be cleaned frequently, dependant on use (minimum monthly).

Aluminium filers are dishwasher safe or can be cleaned with hot soapy water. Ensure that filters are thoroughly dry before re-installing. Slight discolouration may occur when cleaned in the dishwasher.

LAMPS

Your rangehood is fitted with GU10+C halogen lamps. Before replacing, ensure that lamps are completely cool and the power to the unit has been switched off. Replacement lamps can be purchased from your nearest service centre.

To remove the lamp, twist the lamp in an anti-clockwise direction. Be careful when installing the new lamp not to make contact with the skin as this may damage the lamp and shorten its life.

















PRODUCT SPECIFICATION



MODEL: ARU52S SERIAL:

230V ~ 50Hz Lights 2 x 35W Total: 210W Motor: 140W

www.aristonbrand.com

For service please call: Australia: 1300 815 589

New Zealand: 09 306 1020







MODEL: ARU70S SERIAL:

230V ~ 50Hz Lights 2 x 35W Total: 210W Motor: 140W

www.aristonbrand.com

For service please call: Australia: 1300 815 589 New Zealand: 09 306 1020











pg 9













ATTACH YOUR PROOF OF PURCHASE FOR FUTURE REFERENCE









































CONTACT DETAILS

AUSTRALIA

ARISIT PTY LIMITED
40-44 Mark Anthony Drive
Dandenong South, VIC 3175
Australia
Ph 1300 815 589
FX (03) 9768 0838
consumer.care@arisit.com

NEW ZEALAND

ARISIT PTY LIMITED
PO Box 68-140
Newton, Auckland
1145
New Zealand
Ph (09) 306 1020
FX (09) 302 0077
sales@aristonappliances.co.nz

ARISTON IS COMMITTED TO ONGOING RESEARCH AND DEVELOPMENT. EVERY EFFORT HAS BEEN MADE TO ENSURE ALL INFORMATION IN THIS USER MANUAL IS CORRECT AT TIME OF GOING TO PRINT.

DIMENSIONS SHOULD BE USED AS A REFERENCE ONLY AND ACTUAL DIMENSIONS SHOULD BE TAKEN FROM THE PHYSICAL PRODUCT ONLY.

MANUFACTURER RESERVES THE RIGHT TO CHANGE SPECIFICATIONS





